

TIPS 'N' TRICKS



QM-TASQUE INSTALLATION

Use this same method for applying QM-TASQUE to a table top or on the floor.

*Try on a small inconspicuous area **FIRST** to make sure adhesive does not damage the surface*

Prepare Surface

- 1 Wipe down entire area before application. Use filtered water with no chemicals. Use 10% alcohol solution for dirty areas.
- 2 With the print side down, pull back the liner about 8 inches from the top exposing the adhesive. Crease liner as shown.
- 3 Starting at the top of the table, Position the exposed adhesive side to the table flush with the edge. Burnish TASQUE with the roller/squeegee working from the center outward, side to side pushing out any air pockets, as you pull the liner out directly toward the floor. **DO NOT INSTALL IN DIRECT SUNLIGHT TO AVOID HIGH TEMPERATURES DURING INSTALLATION.**
- 4 Continue this method until reaching the end of media.

